

INSTALLER GUIDE FLAT2000L/R

HOME IMPROVEMENT UNIT (FOR FLATS)

**(models fitted with additional
boost speed facility and heater)**

NUAIRE

Home Ventilation

NuAire Home Ventilation
Western Industrial Estate, Caerphilly,
Mid Glamorgan CF83 1XH
Telephone: 08705 002 555
Facsimile: 08705 002 666
Email: info@nuaire.co.uk
www.nuaire.co.uk

Leaflet 670901

DECEMBER 2001

The FLAT2000 L/R is a 'handed' product.
The L/R signifies the discharge direction viewed from
the front.

The **FLAT2000 L** unit is supplied arranged for LEFT
HAND discharge of air

The **FLAT2000 R** unit is supplied arranged for RIGHT
HAND discharge of air


Units are supplied assembled and include a thermostati-
cally controlled heater. A unit mounted override switch
is provided. A 'BOOST' speed facility for additional
ventilation is included. This is operated by a remote
switch (supplied)

ELECTRICAL DETAILS

Supply: 230V 1 phase 50Hz

Power consumption (watts): Low speed= 8. Med=14.
High= 22. Boost = 72.

Customer installation wiring



Wiring the remote switch

